

EVOLUTION D5 FRONT BASKET

KIT INCLUDES:

Front Basket
Basket Bracket
WR D5 Front Basket Brackets
Hardware (2 – Long Bolts, 4 - Short Bolts, 4 – Lock Nuts & 4 – Flat Washers)

Find Instructional Video Here!

<https://linktr.ee/wintersrecreationparts>



TOOLS NEEDED:

13mm Wrench
14mm Wrench
Screwdriver

INSTRUCTIONS

1. Remove front strut canopy bolts using 13mm wrench.
2. Starting on the passenger side, lift grommets on front struts.
3. Remove bottom bolts from front struts using 13mm wrench.
4. Install brackets: Left for passenger side, Right for driver side. Holes should face inward.
5. Use a screwdriver to align strut holes.



6. Using one of the longer bolts from the hardware kit, install the bolt with a washer through the top hole of the bottom of the strut.

Do not fully tighten.

7. Reinstall bolt and washer to the bottom hole on the strut.

Do not fully tighten.

8. Repeat on drivers side.

9. Set basket on top of brackets.

10. Install the basket utilizing the bolts from the kit.

Do not fully tighten until all have been installed.

11. Tighten the two bolts closest to the windshield first using a 13mm wrench.

13. Reinstall top strut bolts to secure canopy (may require 2 people). Fully tighten canopy bolts using 13mm wrench

14. Fully tighten bracket bolts to struts using 13mm wrench.

15. Press grommets back into place.

